

## MOUNTING KIT



CopBox models selected for 2007-2014 Tahoes will also include spacers for the rear mounting bolts.

**WE BUILD IT BETTER**

**CopBox** ONLY FROM CTECH  
**CABINETS** TACTICAL<sup>®</sup>  
STORAGE

CHEVROLET TAHOE  
**COPBOX**  
**INSTALLATION GUIDE**

**CTECH**  
MANUFACTURING  
ALUMINUM CARTS, CABINETS & DRAWERS

7501 Commerce Dr  
Weston, WI 54476

715.355.8842



## TAHOE INSTALLATION STEPS:

### 1. \*2015 and newer\*

Measure 8.25" and 35.75" off the passenger side and 6" off the rear cargo sill trim and mark locations. Drill .75"-1" holes in the factory cargo floor revealing factory mount locations below.



### 1. \*2007-2014\*

No drilling required as the mount locations will be exposed, spacers are included with kit.



2. Flip up rear seats and remove factory nuts. Place front Z-Rail mounting brack on the seat stud and reinstall factory nuts.



3. (2 person job) Place CopBox Cabinet in the rear of cargo area in SUV and slide forward into Z-Rail front mount. Line up rear holes in base.



4. Fasten CopBox Cabinet into place.



4. Reinstall CopBox Cabinet drawer making sure the slides securely fit into the roller bearing cage without binding.

