




WE BUILD IT BETTER



CopBox ONLY FROM CTECH
CABINETS TACTICAL[®]
STORAGE

*CHEVROLET SUBURBAN
COPBOX
INSTALLATION GUIDE*


CTECH
MANUFACTURING
ALUMINUM CARTS, CABINETS & DRAWERS

*7501 Commerce Dr
Weston, WI 54476*

715.355.8842



TACTICAL



SUBURBAN INSTALLATION STEPS:

1. Flip up factory floor and remove dividers and floor mats.



2. Remove factory cargo screws and pull out factory cargo floor.



3. Remove drawer from CopBox Cabinet for installation.



4. (2 person job) Place Cabinet in the rear of vehicle and set into place. The holes in the base should line up with factory mount locations and fasten into place.



5. Reinstall drawer into CopBox Cabinet. make sure slides fit into roller bearing case securely without binding up.

